



CM ALMY

ALMY WOOD PASCHAL CANDLE STAND ASSEMBLY INSTRUCTIONS

Contents:

- 1 Stand Base (12" square panel with corner feet)
- 1 Shaft
- 1 Stand Top (9" square panel with center hole)

Step 1: Attach Stand Base to Shaft

- A** Identify Stand Base. This is the 12" square part with the corner feet.
- B** Identify the Shaft. The bottom end of the shaft has a shaped molding. At its center it has a steel hex nut and washer on a threaded bolt, and, slightly off-center, it has a brass alignment pin.
- C** Unscrew nut and remove washer from bottom of the shaft.
- D** Fit base and washer onto the bolt, rotate until its alignment hole fits the alignment pin in the shaft. Gently press base onto the alignment pin until it is flush against the shaft, then fasten with nut. Tighten using a $\frac{1}{2}$ " wrench or socket drive.

Step 2: Attach Stand Top to Shaft

- A** Unscrew the brass Threaded Stud Adapter from the bolt at the center of top of the shaft. Note, also, the off-center alignment pin in the shaft top.
- B** Making sure that the rounded edges are up, set Stand Top onto the bolt on the shaft. Rotate until the top's alignment hole fits the pin in the shaft top. Press top down onto the alignment pin until it is flush with the shaft.
- C** Fasten the stand top with the brass Threaded Stud Adapter, and tighten securely using a $\frac{5}{8}$ " wrench or socket drive.

Step 3 — Optional, if you ordered a socket for your candle stand:

- A** Locate the brass socket in the package.
- B** Screw socket onto threaded stud on stand top. You can easily screw it in place using your fingers. Use soft gloves or wipe off finger prints with a soft cloth after fastening the sockets.

800.225.2569 www.almy.com



AIK305-1

AS305N-1