



CM ALMY

OUTFITTERS TO THE CHURCH & CLERGY

Liquid Candle Wick Care, Installation, Adjustment

Almy QuickWicks® are specially designed to work with your Almy (or Kerry) liquid candles.

Wick Height Adjustment

When candles first arrive from Almy, or as they are handled in church over time, the QuickWick® height may vary from the ideal $\frac{1}{8}$ ". Simply use the attached T pin and follow the instructions above for adjusting the height of your wicks.

Wick Care

- Never trim or cut QuickWicks®. Liquid candles don't burn down and neither do QuickWicks®. Made of pure fiberglass, they will last at least 1,000 hours if you burn Kerry Liquid.
- Maintain correct wick height of about $\frac{1}{8}$ " to achieve flame height of $\frac{5}{8}$ ". Do not expose more wick to create a larger flame. This creates excess carbon build-up on the wick and rapid consumption of liquid.
- Remove carbon build-up. Use a cloth moistened with Kerry Liquid to pinch carbon off QuickWicks®.

*Free QuickWicks® for Almy's Kerry Liquid Customers —
1-800-225-2569 or www.almy.com*


To keep your candles looking their best use the **Almy Candle Cleaning Kit**. It includes a light polish for brass parts and a safe, organic cleanser for the nylon candle body. Perfect for your Liquid Candles.

800.225.2569 www.almy.com

Installing New Wicks

In time, heat will fuse the fibers in QuickWicks® and they will become less efficient at drawing liquid from the candle. *Free replacement QuickWicks® are available for Almy's Kerry Liquid Customers: call 1-800-225-2569 or visit www.almy.com.*

- Remove old wick. Make sure the candle-top is cool. Unscrew the candle top and pull the old wick from below the wick holder.
- Thread copper wire (attached) through the top loop of the QuickWick®.
- Push the wire ends into the wick holder from the underside of the candle-top. When wire ends appear at the top of the wick holder, pull on them until the wick loop appears. Remove the wire.



- Insert the T pin (attached) into the wick loop and pull gently on the wick from below the candle-top until the wick is tight around the pin at the top of the wick holder. This insures the correct height for the wick and flame.
- Replace the wick and candle top on the body of the candle. Allow a few moments for it to be completely moistened by Kerry Liquid before lighting.

