
Banner Stand Parts



Banner Stand


Assembly Instructions


Your Banner Stand should arrive in separate packages which will include: **A** Banner Pole Finial Cross; **B** Brass Hook with two Brass Wood Screws; **C** Banner Crossbar (one 44" wood section, with brass "acorns" at the ends and pre–installed brass eye.) Two Banner Pole Sections (wood sections with brass fittings): **D** Upper section has the plain top brass fitting; **E** Lower section has a rubber "foot" at the bottom end; **F** Brass Banner Pole Base.

To Assemble Banner Stand

Assemble Banner Pole: screw cross finial


A to top of upper pole section D. Screw
upper and lower pole sections together.





Affix Brass Hook **B** to the Pole.

Determine the height at which you want your banner to hang. Mark drill spots and drill. Screw the brass hook to the pole with the brass screws provided.



Attach Banner to Crossbar C. Slide loops of banner over the crossbar and center. Slide the brass eye on crossbar over the brass hook on the pole.

Adjust banner from side to side until it is balanced and even.

